


BDF22/32/42/52/62

Exploded parts diagram





Part Number	Number	Description	Qty
***	1	Outer cabinet	1
***	2	Glass door	1
***	3	Glass door	1
***	4	Glass Block	1
B9-BASKET01	5	Food Basket (BDF22/32/42/52/62)	2,3,4, 5 or 6
B9-CASTOR01	6	Unbraked Castors (BDF22/32/42)	2
B9-CASTOR02		Braked Castors (BDF22/32/42)	2

B9-CASTOR01	6	Unbraked Castors (BDF52/62)	4
B9-CASTOR02		Braked Castors (BDF52/62)	2
B9-LIGHT01	7	Light Bar (BDF22)	1
B9-LIGHT	7	Light Bar (BDF32 & BDF42)	1
B9-LIGHT02	7	Light Bar (BDF62)	1
B9-LIGHT 093	7	Light Bar (BDF52)	1
B9-SWITCH03	8	Switch	1
B9-SWITCH04	9	Green light	1
B9-THERM	10	Temperature display	1
B9-STAT	11	Thermostat	1
***	12	Thermostat knob	1
B9-TRANS	13	Transformer	1
B9-COMP07	14	Compressor (BDF22/32/42)	1
B9-COMP08		Compressor (BDF52/62)	1
***	15	Side Cover	1
***	16	Power cord	1
B9-3906	17	Filter	1
B9-COND04	18	Condenser	1
***	19	Fan	1
***		Fan	1
***	20	Defrost shovel	1
***	21	User manual	1
***	22	Carton	1
B9-LOCK01	23	Lock and Key	1

*** Please contact Spares for assistance ***