


BIM230

Exploded parts diagram








Part Number	No.	Description	Qty
L3-COIL03	1	Hot Gas Coil	1
L3-HP01	2	High Pressure Switch	1
L3-CONDFAN03	3	Cond Fan Motor	1
L3-MS03	4	Ice Level Switch	1
N/A	5	N/A	N/A
L3-IV03	6	Water Inlet Valve	1
L3-DV01	7	Dump Valve	1
***	8	Electrical Box Cover	1
L3-PCB01	9	PCB (C/W Display)	1
***	10	Display Panel (see No. 8)	1
***	11	Electrical Box	1


*** Please contact Spares for assistance***





Part Number	No.	Description	Qty
L3-SPRAYBAR03	1	Spray Bar	1
***	2	Spray Bar Hose	1
***	3	Dump Valve Hose	1
***	4	Feeder Tube	1
L3-PUMP03	5	Water Pump Assy	1
L3-TANK03	6	Water Reservoir	1


*** Please contact Spares for assistance***





Part Number	No.	Description	Qty
***	1	Grille	4
L3-FILTER03	2	Condenser Filter	4
***	3	Left Side Panel	1
***	4	Top Panel	1
***	5	Machine Frame	1
***	6	Front Panel	1
***	7	Rear Panel	1
***	8	Right Side Panel	1
***	9	Compressor Plate	1
***	10	Bottom Plate	1
***	11	Base	1
***	12	Control Panel Frame	1
***	13	Control Panel Cover	1

*** Please contact Spares for assistance***





Part Number	No.	Description	Qty
L3-EC01	1	Evaporator Curtain	1
***	2	Evaporator	1
***	3	Drier	1
L3-TEV01	4	Expansion Valve	1
L3-HGV03	5	Hot Gas Valve (body)	1
***	6	Accumulator	1
***	7	Discharge Pipe	1
***	8	Suction Pie	1
L3-COND03	9	Condenser	1
L3-COMP03	10	Compressor	1

*** Please contact Spares for assistance***